InnoFlue Appliance Adaptor Quick Guide

InnoFlue is approved for use on almost all boilers, water heaters, and furnaces.

The adaptors below are the most common starter pieces adapting to **InnoFlue** (2"-12" diameters) directly off of the appliance.

To find your **InnoFlue** starter piece:


- 1. Scan the QR at bottom and open the **InnoFlue** OEM Appliance Adaptor Matrix
- 2. Locate the appliance to be installed by type (boiler / water heater / furnace)
- 3. Find corresponding InnoFlue component by manufacturer and model





Most Common InnoFlue Starter Pieces

No Adaptor	ISAAL	ISAGL	ISAFLG	ISSA
Appliance takes InnoFlue SW Rigid directly with no adaptor	Adapts a female PVC/CPVC sized appliance collar (with integrated gasket) to InnoFlue SW Rigid	Adapts a female PVC/CPVC coupler or appliance flue to InnoFlue SW Rigid	Adapts to InnoFlue SW Rigid with bolt-down flange.	Adapts a stainless steel appliance flue exhaust (with gasket and clamp) to InnoFlue SW Rigid
			Note: More common in larger diameters	



NOTE: The **InnoFlue** parts listed above are the most commonly used adaptors, but several appliances require custom adaptors and additional components.

Always refer to OEM Matrix for the specific part numbers necessary to begin your flue gas run.

